

Was macht/ist die Datei 1251829v3 ?

- Die Datei ist ein sogenannter Patch.
Ein **Patch** (von engl. *to patch* = flicken, ausbessern und *patch* = [aufgesetzter] Flicker, Flickwerk in der Bedeutung von *Reparatur bzw. Nachbesserung*) ist eine Korrekturauslieferung für [Software](#) oder [Daten](#) aus Endanwendersicht, um Fehler zu beheben.
- Dieser Patch behebt eine mögliche Fehler-Quelle die zum einfrieren ihres Druckers, defekt des internen Controllers und somit zu einem Totalausfall ihres Geräts führt.
- Dieser Patch kommt vom Hersteller Xerox und beinhaltet keinerlei schädliche oder versteckte Daten. Er ist nur dazu da, dass die auf dem Controller-Board verbaute SD-Karte gelesen werden kann. Dies alles ist ein interner Prozess der bei jedem Neustart des Geräts gemacht wird.

Product Technical Overview

Machine Run Control

Overview: Controller

The heart of the system is the Controller, which is pictured at the right with key features called out.

To help determine the operation of the Controller, a 7-segment display displays numbers and letters indicating the Controller state.

NOTE: The SD Card (to enable machine speed), and 1GB DDR2 EPC Memory (Image Processing - 64 bit) are located behind the Fax mounting plate, which is removed for clarity.

SD-Karte (von englisch Secure Digital Memory Card)

